

Communications Card Operation

Table of Contents

Section	Page	Section	Page
Introduction		What Matlink Can Do	9
Qualified Persons	2	Viewing Micro-AT Control Settings	10
Read this Instruction Sheet.	2	Changing Micro-AT Control Settings	13
Retain this Instruction Sheet.	2	Creating a Configuration File	17
Proper Application.	2	Downloading a Configuration File.	20
Warranty	2	Sending a Configuration File to Micro-AT	21
General.	3	Viewing the “Not Ready” List.	22
Safety Information		Troubleshooting Data-Line Circuit Problems	23
Understanding Safety-Alert Messages	5	Uploading the Micro-AT Control Event Log.	24
Following Safety Instructions	5	Creating an Events File.	27
Replacement Instructions and Labels.	5	Appendix	
Using the Communications Card		Setting a Default Configuration	29
Installing Matlink™ on Your Computer Hard Drive	6		
Running Matlink	6		

NOTICE

- Follow these recommendations when using Matlink Communication Software Version 2.5 B:
1. Always end each session by highlighting and selecting **File** on the menu bar, then highlighting and selecting **Exit**. Using the “—” in the upper left-hand corner of the window, when operating under Windows® 3.X, or the “X” in the upper right-hand corner of the window, when operating under Windows® 95, Windows® 98, Windows® 2000, Windows NT®, Windows XP®, or Windows® 7, may not terminate the application. You may need to open the Windows Task Manager and select “**Matlink.exe**” to exit the application.
 2. Set the screen area to at least 800 by 600 pixels. A lesser setting may result in viewing and/or mouse operation difficulties.



Introduction

Qualified Persons

WARNING

The equipment covered by this publication must be installed, operated, and maintained by qualified persons who are knowledgeable in the installation, operation, and maintenance of electric power distribution equipment along with the associated hazards. A qualified person is one who is trained and competent in:

- The skills and techniques necessary to distinguish exposed live parts from non-live parts of electrical equipment.
- The skills and techniques necessary to determine the proper approach distances corresponding to the voltages to which the qualified person will be exposed.
- The proper use of the special precautionary techniques, personal protective equipment, insulating and shielding materials, and insulated tools for working on or near energized parts of electrical equipment.

These instructions are intended only for such qualified persons. They are *not* intended to be a substitute for adequate training and experience in safety procedures for this type of equipment.

Read this Instruction Sheet

Thoroughly and carefully read this instruction sheet before operating your Micro-AT Source-Transfer Control. Familiarize yourself with “Safety Information” on page 5. The latest version is available online in PDF format at www.sandc.com. > **Support** > **Product Literature**.

Retain this Instruction Sheet

This instruction sheet is a permanent part of your Micro-AT Source-Transfer Control. Designate a location where you can easily retrieve and refer to this publication.

Proper Application

CAUTION

The equipment in this publication must be selected for a specific application. The application must be within the ratings furnished for the equipment.

Warranty

The warranty and/or obligations described in S&C’s standard conditions of sale, as set forth in Price Sheet 150, plus any special warranty provisions, as set forth in the applicable product-line specification bulletin, are exclusive. The remedies provided in the former for breach of these warranties shall constitute immediate purchaser’s or end user’s exclusive remedy and a fulfillment of all seller’s liability. In no event shall seller’s liability to immediate purchaser or end user exceed the price of the specific product which gives rise to immediate purchaser’s or end user’s claim. All other warranties whether express or implied or arising by operation of law, course of dealing, usage of trade or otherwise, are excluded. The only warranties are those stated in Price Sheet 150, and THERE ARE NO EXPRESS OR IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. ANY EXPRESS WARRANTY OR OTHER OBLIGATION PROVIDED IN PRICE SHEET 150 IS GRANTED ONLY TO THE IMMEDIATE PURCHASER AND END USER, AS DEFINED THEREIN. OTHER THAN AN END USER, NO REMOTE PURCHASER MAY RELY ON ANY AFFIRMATION OF FACT OR PROMISE THAT RELATES TO THE GOODS DESCRIBED HEREIN, ANY DESCRIPTION THAT RELATES TO THE GOODS, OR ANY REMEDIAL PROMISE INCLUDED IN PRICE SHEET 150.

Understanding Safety-Alert Messages

There are several types of safety-alert messages which may appear throughout this instruction sheet as well as on labels affixed to the gear. Familiarize yourself with these types of messages and the importance of the various signal words, as explained below.

General

This publication provides instructions for use of the optional communications card feature for the Micro-AT Source-Transfer Control (Catalog Number Suffix “-Y8”). See Figure 1. This feature permits local uploading of the Micro-AT control’s “events,” operating characteristics and operating parameters, digital input and output states, and messages explaining why the automatic-transfer “ready” indicating lamp isn’t lighted. This feature also allows local downloading of the user’s standard operating parameters to the Micro-AT control.

To use the communications card feature, you’ll need the following:

- An IBM PC AT or compatible computer using Intel’s 80386 microprocessor, or higher. The computer must have a minimum of 2 MB of memory, a CD-ROM drive, and a hard disk drive with at least 2MB of free space. The computer must operate under Microsoft Windows™, Version 3.X, Windows® 95, Windows® 98, Windows® 2000, Windows® NT, Windows® XP, or Windows® 7-32-Bit.
- To use Windows® 7 64-Bit Operating System, the system version must be Professional or Ultimate. Both include XP Mode, which is required to use the Micro-AT Communications Card. Also note that the XP Mode virtual machine must be configured to use a serial port on the computer (if one exists), or a USB-to-Serial adapter, and the USB-to-Serial driver must be installed on the XP Mode virtual machine.

Windows® 7 XP Mode	Windows 7 64-Bit		Windows 7 32-Bit	
	Serial Port	USB-to-Serial	Serial Port	USB-to-Serial
	Does not work	Does not work	Works correctly	Works correctly
	Works correctly	Works correctly		

- A Micro-AT communication cable. This cable is available from S&C in two versions: Catalog Number TA-2320 for personal computers having a 25-pin serial communication port and Catalog Number TA-2321 for personal computers having a 9-pin serial communication port.
- Matlink™ communication software, is available for download at www.sandc.com>Support S&C Automation Customer Support Portal. If you need assistance, please contact customerportal@sandc.com or phone (800) 621-5546.

NOTICE

Use the following table to determine the version of MATLink compatible with the firmware of your Micro-AT control.

Micro-AT Firmware Version	Matlink Version	Matlink Issue Date
V2.0.2	You must upgrade to at least V2.1.2 to use the communications card.	—
V2.1.2	V2.1	6/15/96
V2.2.1	V2.2	9/14/96
V2.4.0	V2.4	10/10/98
V2.5.0 through V2.5.6	V2.5	7/14/00
V2.5.0 through V2.5.6	V2.5A	3/6/01
V2.5.0 through V2.5.6	V2.5B	9/20/02
V2.5.7	V2.5C	6/3/05
V2.6.0	V2.6	9/1/09
V2.6.1	V2.6	9/1/09

To determine the Micro-AT firmware version, press the “EXAMINE” menu key followed by the “Next Item” key. The version of the Micro-AT firmware will be displayed. For example, in the display below, the Micro-AT Firmware version is 2.1.2.

EXAMINE: 2.1.2
COPYRIGHT S&C 1990-1995




Figure 1. Communications card option for Micro-AT Source-Transfer Controls.

⚠ DANGER

“DANGER” identifies the most serious and immediate hazards which *will likely* result in serious personal injury or death if instructions, including recommended precautions, are not followed.

⚠ WARNING

“WARNING” identifies hazards or unsafe practices which *can* result in serious personal injury or death if instructions, including recommended precautions, are not followed.

⚠ CAUTION

“CAUTION” identifies hazards or unsafe practices which *can* result in minor personal injury or product or property damage if instructions, including recommended precautions, are not followed.

NOTICE

“NOTICE” identifies important procedures or requirements that, if not followed, *can* result in product or property damage if instructions are not followed.

Following Safety Instruction

If you do not understand any portion of this instruction sheet and need assistance, contact your nearest S&C Sales Office or S&C Authorized Distributor. Their telephone numbers are listed on S&C’s website www.sandc.com. Or call S&C Headquarters at (773) 338-1000; in Canada, call S&C Electric Canada Ltd. at (416) 249-9171.

NOTICE

Thoroughly and carefully read this instruction sheet before operating your Micro-AT Source-Transfer Control.



Replacement Instructions and Labels

If you need additional copies of this instruction sheet, contact your nearest S&C Sales Office, S&C Authorized Distributor, S&C Headquarters, or S&C Electric Canada Ltd.

It is important that any missing, damaged, or faded labels on the equipment be replaced immediately. Replacement labels are available by contacting your nearest S&C Sales Office, S&C Authorized Distributor, S&C Headquarters, or S&C Electric Canada Ltd.

Before proceeding, refer to Quick-Start Programming Instruction Sheet 515-530 or Instruction Sheet 515-500 or 515-600 for instructions on field programming and operation of the Micro-AT Source-Transfer Control.

Installing Matlink™ on Your Computer Hard Drive

NOTICE

Matlink™ communication software, is available for download at www.sandc.com> Support> S&C Automation Customer Support Portal. If you need assistance, please contact customerportal@sandc.com or phone (800) 621-5546.

Go to the S&C Automation Customer Support Portal, open the Matlink Workspace, and download the appropriate Matlink Software installer to your desktop. Unzip the downloaded folder, and save the folder contents to your desktop. Double click the program **INSTALL.EXE** that you saved on the desktop. This will install Matlink Software on your computer.

To start Matlink, click your Start button and select **All Programs**. Open the Matlink V2.xx folder and double click the Matlink program inside the folder.

Running Matlink

⚠ CAUTION

The steps which follow describe the procedure for running Matlink with a Micro-AT Source-Transfer Control connected to your personal computer. Matlink can also be run—and configurations▲ created—without a Micro-AT control connected to the personal computer. If you wish to create a configuration(s) for later downloading, proceed to “**APPENDIX**” on page 16.

Step 1

Place the manual/automatic operation selector switch on the Micro-AT Source-Transfer Control in the “MANUAL” position.

Step 2

Decouple each operator from its interrupter switch—changing the Micro-AT configuration might cause a temporary service interruption. Refer to the S&C instruction sheet furnished with the pad-mounted gear, metal-enclosed switchgear, or Vista® Underground Distribution Switchgear or, in weatherproof enclosure applications, the S&C instruction sheet furnished with the switch operators.

Step 3

Loosen the screw which retains the hinged lower panel of the Micro-AT control and swing open the lower panel. See Figure 1 on page 4. (In pad-mounted gear which was originally furnished with a Type AT-12 Source-Transfer Control, loosen the two screws which retain the door assembly of the Micro-AT control and swing open the door assembly.)

Step 4

With your computer off, connect the communication cable between the serial port of the computer and the communication port of the Micro-AT control. A USB-to-Serial adapter is required if your computer does not have a Serial port.

▲ A configuration consists of the settings of the Micro-AT control, which include its operating characteristics and its voltage-, current-, and time-related operating parameters.


Step 5

NOTICE
Help screens have been created and are viewable any time Matlink is running.

Turn on the computer.

Double-click on the **MATLINK** icon. Or open the File Manager and select **MAT-LINK**; then highlight and select **MATLINK.EXE**.


The Matlink application will appear as shown below.



Step 6


To establish the communication link between your computer and the Micro-AT control:

- (a) Highlight and select **Communications** on the menu bar. A pop-up menu will appear listing communications options as shown below.




Using the Communications Card

- (b) Select the bit rate and port by highlighting and selecting **Settings**. A dialog box will appear listing bit rate and port options as shown below. Select **19200** bps and the appropriate serial port. If you experience data transfer problems, both the Micro-AT and Matlink communication settings should be set to 9600 bps.



- (c) Verify that the status window shows a changing clock display as shown below—indicating that communication with the Micro-AT control has been established. If a problem is encountered in establishing communication, an appropriate dialog box will be displayed explaining the problem. Should you need to change the bit rate at the Micro-AT control, refer to Quick-Start Programming Instruction Sheet 515-530 or Instruction Sheet 515-500 or 515-600 for details.



NOTICE

A help screen is available for communications and troubleshooting.

What Matlink Can Do

Using Matlink, you'll be able to view the following:

- The settings of a Micro-AT control, which include its operating characteristics and voltage-, current-▲, and time-related operating parameters;
- System voltage and current▲ values;
- The status of the Micro-AT control, its associated switch operators, and remote supervisory functions■, and
- The event log of the Micro-AT control.

You'll also be able to save to file the Micro-AT settings and the event log. You'll have the capability of changing most settings of the Micro-AT control, either from your computer or from a file.

If necessary, you can use Matlink to view messages explaining why the automatic-transfer "ready" lamp on a Micro-AT control isn't lighted. And when troubleshooting data-line circuit problems, you'll be able to examine the status of digital inputs to the control and digital outputs from the control.

The event log is available in two formats, *.log and *.csv. The configuration data is also available in two formats, *.cfg and *.txt. The *.log file can be viewed using an application such as Microsoft® Notepad or Microsoft® Word.

▲ Applicable to installations furnished with overcurrent lockout feature.


■ Applicable to installations furnished with supervisory control feature.

Viewing Micro-AT Control Settings

NOTICE

For new Micro-AT installations: Before proceeding, you'll need to normalize the left and right sources to compensate for any output-voltage magnitude and/or phase-angle unbalance between the voltage-sensing devices on that source. You'll also need to set the base voltages on phase 2 of the left and right sources. Each source should be in its known normal state during the execution of the normalizing and set base menu items so that any unusual conditions are calibrated out. Refer to Quick-Start Programming Instruction Sheet 515-500 or 515-600 for details. *Normalizing the sources and setting the base voltages must be performed at the Micro-AT control. These functions cannot be performed using Matlink.*


In the steps which follow, you'll be viewing the settings of items listed in the **Configuration**, **Voltage**, **Current**, and **Time** data windows. You can also access these items by highlighting and selecting **Window** on the menu bar, as shown below, and then highlighting and selecting the appropriate data window.



If any of the field adjustable items need to be changed, refer to “**Changing Micro-AT Control Settings**” on page 13.

Step 7

Click on the **Config** button bar. The **Configuration** data window will appear, similar to that shown below.




The field adjustable items in the **Configuration** data window which can be changed using Matlink include **Unbalance Detect**♦, **Return Mode**♦, **Transition Mode**♦, and **Dwell Timer**. (**Preferred Source** is also field adjustable but cannot be changed using Matlink. If necessary, **Preferred Source** can be changed at the Micro-AT control.)

Bus Type, **Voltage Sensing**, **Unbalance Install**, **Lockout Option**, and **Supervisory Control** are all factory-set and are not field adjustable.

Step 8

Click on the **Voltage** button bar. The **Voltage** data window will appear, similar to that shown below.



♦ This function may have been factory-set so that it is not field adjustable.


Using the Communications Card

The actual left-source and right-source phase voltages, zero-sequence voltages, positive-sequence voltages, and negative-sequence voltages after normalizing are displayed.

The field adjustable items in the **Voltage** data window which can be changed using Matlink include **Loss of Source Level, Return of Source Level, Unbalance Level, and Overvoltage Level.**

Step 9

If **Lockout Option** has been factory-set for “Internal,” click on the **Current** button bar. The **Current** data window will appear, similar to that shown below.




The screenshot shows the MATLINK/Windows V2.6 software interface. The 'Current' button bar is selected. The data window displays the following information:

Voltage	Current	Time	Config	Inputs	Outputs	Not Ready	Event Log
Source		Current	Port Selected: COM1				
Left	GOOD	NORMAL	Not Ready	Vista Com	11/12/07		
Right	GOOD	NORMAL	New Events	Preferred Left	17:01:20		
Current							
Lockout Option		Internal					
Lockout Level		480					
Left Neutral Current		1					
Right Neutral Current		1					

The **Lockout Level** is field adjustable using Matlink.

Step 10

Click on the **Time** button bar. The **Time** data window will appear, similar to that shown below.



The screenshot shows the MATLINK/Windows V2.6 software interface. The 'Time' button bar is selected. The data window displays the following information:

Voltage	Current	Time	Config	Inputs	Outputs	Not Ready	Event Log
Source		Current	Port Selected: COM1				
Left	GOOD	NORMAL	Not Ready	Vista Com	11/12/07		
Right	GOOD	NORMAL	New Events	Preferred Left	16:01:54		
Time							
Loss of Source Left		2.0 seconds					
Loss Of Source Right		2.0 seconds					
Return Of Source		00:03:00 (H:M:S)					
Lockout Reset		20.0 seconds					
Transition Dwell		n/a seconds					
Window Begin Time		01:00:00					
Micro-AT Date		11/12/07					
Micro-AT Time		16:01:54					

The field adjustable items in the **Time** data window which can be changed using Matlink include **Loss of Source Left**, **Loss of Source Right**, **Return of Source**, **Lockout Reset**, **Transition Dwell**, **Window Begin Time**, **Micro-AT Date**, and **Micro-AT Time**.


NOTICE
A help screen is available for viewing settings.

Changing Micro-AT Control Settings

Step 11

If, after checking the factory-settings of items listed under the **Configuration**, **Voltage**, **Current**, and **Time** data windows, you determine that one or more field adjustable items need to be changed:

- (a) Highlight and select **Settings** on the menu bar. A new pop-up menu will appear listing settings options, similar to that shown below.



Using the Communications Card

- (b) Highlight and select **Change**. After a short delay, during which Matlink is retrieving data from the Micro-AT control, the **Change Configuration** data window will appear, similar to that shown below. The present settings and alternative new settings of **Configuration** items are listed. If an item listed in the **Voltage**, **Current**, or **Time** data window is to be changed, proceed to Step 11 (e).

Name	Present Setting	New Setting
Config		
Bus Type	Vista Common	Not Changeable
Preferred Source	Left	Not Changeable
Voltage Sensing	4 Wire	Not Changeable
Unbalance Install	Out	Not Changeable
Unbalance Detect	Off	Not Changeable
Select Return	Auto	Auto
Select Transition	Open	Open
Lockout Option	In	Not Changeable
Dwell Timer	In	In
Supervisory Control	In	Not Changeable

Buttons: Send to AT, Load File, Save to File, More >>, Close

Page 1 of 2

Note that, for factory-set items which are not field adjustable, the alternative settings are shown as “Not Changeable.”


- (c) If an item listed in the **Change Configuration** data window is to be changed, highlight and select the drop-down setting box for the item. For example, if **Select Return** is to be changed from “Auto” to “Hold,” highlight and select the appropriate drop-down setting box. A new window will appear listing the alternative settings, similar to that shown below.

Name	Present Setting	New Setting
Config		
Bus Type	Vista Common	Not Changeable
Preferred Source	Left	Not Changeable
Voltage Sensing	4 Wire	Not Changeable
Unbalance Install	Out	Not Changeable
Unbalance Detect	Off	Not Changeable
Select Return	Auto	Auto
Select Transition	Open	Open
Lockout Option	In	Not Changeable
Dwell Timer	In	In
Supervisory Control	In	Not Changeable


Buttons: Send to AT, Load File, Save to File, More >>, Close

Page 1 of 2

(d) In this example, select **Return** “Auto.” The following screen will appear.




(e) If an item listed in the **Voltage**, **Current**, or **Time** data window is to be changed, click on the **More >>** button. A new window will appear, similar to that shown below.



Using the Communications Card


- (f) Highlight and select the edit box for the affected item. For example, if **Loss of Source** voltage is to be changed from “85.0” to “83.0,” highlight and select the present setting. The following screen will appear:



Name	[Setting Range]	Present Setting	New Setting
Voltage			
Loss of Source	[10.0 Volts to 105 Volts]	85.0 Volts	83.0
Return of Source	[100 Volts to 120 Volts]	105.0 Volts	105.0
Overvoltage Level	[120 Volts to 140 Volts]	135.0 Volts	135.0
Unbalance Level	[12.0 Volts to 60.0 Volts]	N/A	
Current			
Lockout Level	[200 Amps to 1500 Amps]	480 Amps	480
Time			
Loss of Left	[0.25 to 240 seconds]	2.00 Seconds	2.00
Loss of Right	[0.25 to 240 seconds]	2.00 Seconds	2.00
Return of Source	[5 sec - 8 hours]	00:10:00 [H:M:S]	00:10:00
Lockout Reset	[0.25 to 240 seconds]	20.00 Seconds	20.00
Return Dwell	[0.25 to 10.0 seconds]	2.0 Seconds	2.0
Window Begin	01:00 [H:M]	01:00	

Page 2 of 2

- (g) Enter the desired value. The following screen will appear.



Name	[Setting Range]	Present Setting	New Setting
Voltage			
Loss of Source	[10.0 Volts to 105 Volts]	85.0 Volts	83.0
Return of Source	[100 Volts to 120 Volts]	105.0 Volts	105.0
Overvoltage Level	[120 Volts to 140 Volts]	135.0 Volts	135.0
Unbalance Level	[12.0 Volts to 60.0 Volts]	N/A	
Current			
Lockout Level	[200 Amps to 1500 Amps]	480 Amps	480
Time			
Loss of Left	[0.25 to 240 seconds]	2.00 Seconds	2.00
Loss of Right	[0.25 to 240 seconds]	2.00 Seconds	2.00
Return of Source	[5 sec - 8 hours]	00:10:00 [H:M:S]	00:10:00
Lockout Reset	[0.25 to 240 seconds]	20.00 Seconds	20.00
Return Dwell	[0.25 to 10.0 seconds]	2.0 Seconds	2.0
Window Begin	01:00 [H:M]	01:00	

Page 2 of 2

If the operating characteristics and operating parameters are *not* to be saved to your computer as a configuration file, proceed to “**Sending a Configuration File to the Micro-AT Control**” on page 21.


NOTICE

A help screen is available for changing settings.


Creating a Configuration File

Step 12

To save to your computer the particular set of operating characteristics and operating parameters that you've checked and/or revised in **Change Configuration**, click on the **Save to File** button. The following screens will appear.



Enter an appropriate name for the configuration file.



Using the Communications Card


Name	(Setting Range)	Present Setting	New Setting
Voltage			
Loss of Source	(10.0 Volts to 105 Volts)	85.0 Volts	83.0
Return of Source	(100 Volts to 120 Volts)	105.0 Volts	105.0
Time			
Loss of Left	(0.25 to 240 seconds)	2.00 Seconds	2.00
Loss of Right	(0.25 to 240 seconds)	2.00 Seconds	2.00
Return of Source	[5 sec - 8 hours]	00:10:00 [H:M:S]	00:10:00
Lockout Reset	(0.25 to 240 seconds)	20.00 Seconds	20.00
Return Dwell	(0.25 to 10.0 seconds)	2.0 Seconds	2.0
Window Begin	01:00 [H:M]	01:00	

You can also save to your computer a particular set of operating characteristics and operating parameters by highlighting and selecting **File** on the menu bar. A new pop-up menu will appear listing file options as shown below.

Current	Time	Config	Inputs	Outputs	Not Ready	Event Log
GOOD	NORMAL	Port Selected: COM1	Not Ready	Vista Com		11/12/07
Right	GOOD	NORMAL	New Events	Preferred Left		16:05:46


Voltage		
	Left	Right
Phase 1	120.1	120.3
Phase 2	120.2	120.5
Phase 3	120.0	120.8
Zero Sequence	0.3	0.1
Positive Sequence	120.2	120.6
Negative Sequence	0.2	0.2
Loss Of Source Level	85.0	
Return Of Source Level	105.0	
Unbalance Level	20.9	
Overvoltage Level	135.0	


Highlight and select **Save Config**. The following screen will appear.



Enter an appropriate name for the configuration file.

In both instances, two files will be created, a binary (*.cfg) file and a text formatted (*.txt) file. A notification prompt will be displayed with the full file location information.






Downloading a Configuration File

Step 13

To download to your computer a particular configuration file that was created in **Settings**, click on the **Load File** button. The following screen will appear.



Enter the name of the desired configuration file.


NOTICE

A help screen is available for configuration download.

Sending a Configuration File to Micro-AT

Step 14

To send to the Micro-AT control a configuration file that you've just created or a configuration file that you've just downloaded to your computer in **Settings**, click on the **Send to AT** button. After a short delay, during which Matlink is transmitting data to the Micro-AT control, the following screen will appear.





Enter the access code.

Error messages are shown on the following screens.

NOTICE

A help screen is available for sending configuration files.






NOTICE

Matlink compares the factory-set items already present in the CONFIGURE menu of the Micro-AT control with the factory-set items of the configuration file that you've just sent. If there are any conflicts between them, the updated configuration will not be accepted.

For instance, if the CONFIGURE menu of the control has been factory-set for a common-bus metal-enclosed switchgear application, then a configuration for a pad-mounted gear application cannot be entered into the control.

Viewing the "Not Ready" List

To view messages explaining why the automatic-transfer "ready" lamp on the Micro-AT control is not lighted, click on the **Not Ready** button bar. The following screen will appear.



In this particular case, the "ready" lamp is not lighted on the Micro-AT because the manual/automatic operation selector switch on the Micro-AT control is in "MANUAL", the Right Operator is not in the Open position, the Left Operator is not in the Closed position, and the Low Tank Pressure alarm is active.

NOTICE

A help screen is available for viewing the not ready list.

**Troubleshooting
Data-Line Circuit
Problems**

If, in the course of troubleshooting a Micro-AT control in accordance with Instruction Sheet 515-520, it becomes necessary to diagnose a data-line circuit problem, the digital inputs to the control and digital outputs from the control can be examined using Matlink.

To view digital inputs to the Micro-AT control, click on the **Inputs** button bar. The following screen will appear.

Voltage	Current	Time	Config	Inputs	Outputs	Not Ready	Event Log
Source		Current		Port Selected: COM1			
Left	GOOD	NORMAL		Not Ready	Vista Com	11/12/07	
Right	GOOD	NORMAL		New Events	Preferred Left	17:03:08	
Digital Inputs							
		Left	Right	Tie			
Operator Open	False	False	False	n/a			
Operator Closed	False	False	False	n/a			
Operator Coupled	n/a	n/a	n/a	n/a			
Operator Grounded	False	False	False	n/a			
Manual Trip Close	n/a	n/a	n/a	n/a			
Shutter Interlock	n/a	n/a	n/a	n/a			
Tank Pressure Low	n/a	n/a	True	n/a			
Supervisory Trip Open	n/a	n/a	n/a	n/a			
Supervisory Trip Close	n/a	n/a	n/a	n/a			
Charged To Open	n/a	n/a	n/a	n/a			
Charged To Close	n/a	n/a	n/a	n/a			
Capacitor Charged	n/a	n/a	n/a	n/a			
Ext. Overcurrent Reset	False	False	False				
Ext. Overcurrent Set	n/a	n/a	n/a				

The true/false operating responses of the snap-action limit switches (and key interlocks, if applicable) at the inputs of the control are shown.

To view digital outputs from the Micro-AT control, click on the **Outputs** button bar. The following screen will appear.

Voltage	Current	Time	Config	Inputs	Outputs	Not Ready	Event Log
Source		Current		Port Selected: COM1			
Left	GOOD	NORMAL		Not Ready	Vista Com	11/12/07	
Right	GOOD	NORMAL		New Events	Preferred Left	17:03:27	
Digital Outputs							
		Left	Right	Tie			
Operator Trip	False	False	False	n/a			
Run Motor	n/a	n/a	n/a				
Steer To Open	False	False	False				
Steer To Close	False	False	False				

The true/false operating responses at the outputs of the control are shown.


NOTICE

A help screen is available for troubleshooting data lines.


Uploading the Micro-AT Control Event Log

The Micro-AT control records system status, as well as software status, every time a change occurs. Each such status change—referred to as an “event”—is indicated by the illumination of a lamp on the “EVENT” menu key of the control. The last 130 events are stored in memory at any given time, in an event log.


To upload the event log of the Micro-AT control to your computer, click on the **Event Log** button bar. The following screen will appear.



Click on the **Load** button. A dialog box will appear as shown below.




Following the completion of the download of the Event Log, the Configuration Event Log will download during which a dialog box will appear as shown below:



Note that the event log overview lists, for each event, the following:

- The event number;
 - The date of the event;
 - The time of the event;
 - The event ID number (see the “Appendix” section of Instruction Sheet 515-500 or 515-600);
 - The event description (the same description indicated in the “Appendix” section of Instruction Sheet 515-500 or 515-600);
 - The condition of the left source during the event; and
 - The condition of the right source during the event.
- You can scroll through the event log as desired. For more detail on a particular event, highlight that event and click on the Detail button. Or double-click on the event. The following screen will appear.



Note that the event log detail lists, for a particular event, the following:

- The event number;
- The date/time of the event;
- The event ID number;
- The left-source phase and unbalance voltages during the event;
- The right-source phase and unbalance voltages during the event;
- The left-source voltage condition during the event (good, bad, or overvoltage);
- The right-source voltage condition during the event (good, bad, or overvoltage);
- The left-source overcurrent state during the event (normal, latch, or reset);
- The right-source overcurrent state during the event (normal, latch, or reset);
- The left-source operator state during the event▼;
- The right-source operator state during the event▼;
- The bus-tie operator state during the event▼;
- The transfer controller state during the event▼; and
- The 16-bit flagword (for factory-diagnostic use).

The event log detail for the next event, the previous event, the oldest event, or the newest event can be obtained by clicking on the **Next** button, the **Previous** button, the **Oldest** button, or the **Newest** button, respectively.

Note that the configuration event log overview lists, for each event, the following:

- The event number;
 - The date of the event;
 - The time of the event;
 - The event ID number (see the “Appendix” section of the Instruction Sheet 515-500 or 515-600).
- ▼ See “DIAGNOSTIC TOOLS” section of Instruction Sheet 515-500 or 515-600.



NOTICE

A help screen is available for uploading the event log.

Using the Communications Card

Enter an appropriate name for the events file.

Two files will be created, a text output (*.log) file, which can be viewed using an application such as Note pad or Word, and a comma delimited (*.csv) file, which can be viewed using Excel.



NOTICE

A help screen is available for creating events files.

Setting a Default Configuration


The steps which follow apply only in instances where a Micro-AT Source-Transfer Control is *not* connected to your personal computer.

Step A

Turn on the computer and run the OS.


Double-click on the **MATLINK** icon. Or open the File Manager (Win 3.1) or Windows Explorer (Win 95+) and select **MATLINK**; then highlight and select **MATLINK.EXE**.

The Matlink application will appear as shown below.




Step B

Highlight and select **Settings** on the menu bar. A pop-up menu will appear listing settings options, as shown below.



Step C

Highlight and select **Change**. The default configuration data window will appear, as shown below.



Step D


Select the default values of all “Not Changeable” items. Refer to Quick-Start Programming Instruction Sheet 515-530 or Instruction Sheet 515-500 or 515-600 for details.

NOTICE


Each default value you select must conform with the corresponding factory-set item in your Micro-AT control(s). When you subsequently download the configuration file you're creating to a particular Micro-AT control, Matlink will compare each default value to the corresponding factory-set item in the CONFIGURE menu of the control. If there are any conflicts, the downloaded configuration will not be accepted.

For instance, if the CONFIGURE menu of the control is presently factory-set for a common-bus metal-enclosed switchgear application, then a configuration for a pad-mounted gear application cannot be entered into the control.

For example, if **Bus Type** is to be changed from “Common” to “Vista Common,” highlight and select the appropriate drop-down setting box. A new window will appear listing the alternative settings, similar to that shown below.



In this example, select **Bus Type** “Vista Common.” The following screen will appear.



After you've selected the default values of all "Not Changeable" items, click on the **OK** button. The **Change Configuration** data window will appear, similar to that shown below.

Name	Present Setting	New Setting
Config		
Bus Type	Vista Common	Not Changeable
Preferred Source	Left	Not Changeable
Voltage Sensing	4 Wire	Not Changeable
Unbalance Install	In	Not Changeable
Unbalance Detect	On	On
Select Return	Auto	Auto
Select Transition	Open	Open
Lockout Option	Out	Not Changeable
Dwell Timer	Out	Out
Supervisory Control	Out	Not Changeable

Page 1 of 2

Proceed to “**Changing Micro-AT Control Settings,**” Step 11(c) on page 14.